

A

B

VBA11001-R.3663.A

1

2

3





















Fig. 8

Parts List

D70s							VBA11001-R.3663.A
Part Number Part Code	Barcode (Part Code)	部品名 Part Name	Pcs./ Unit	fig No.	Main Assembly	Q'ty/ Order	Remarks
* 1B002-260 1B002-260		A/M切替SW部組 A/M CHANGE SW UNIT	1	7		5	
* 1B002-261 1B002-261		Fmin SW部組 Fmin SW UNIT	1	5		5	
* 1B002-371 1B002-371		CF基板押え部組 CF PCB RETAINING UNIT	1	2		5	
* 1B060-866 1B060-866		AF補助光 AF ASSIST LAMP UNIT	1	1		5	
1B060-943 1B060-943		SB下ケース部組 SB LOWER CASE UNIT	1	11		5	
* 1B100-856 1B100-856		ミラーホルダー部組 MIRROR HOLDER UNIT	1	5		1	
* 1C998-414 1C998-414		AF基板部組 AF PCB UNIT	1	6	1C999-340	1	
* 1C998-416 1C998-416		着脱釦部組 LENS RELEASE BUTTON UNIT	1	6	1C999-340	5	
* 1C998-421 1C998-421		SI 偏向板部組 SI POLARIZE PLATE UNIT	2	7		5	
* 1C998-591 1C998-591		中空ペンタ部組 HOLLOW PENTA PRISM UNIT	1	7		1	
* 1C998-592-1 1C998-592		前カバー部組 FRONT COVER UNIT	1	14		5	
* 1C998-594 1C998-594		グリップ部組 GRIP RUBBER UNIT	1	14		5	
△ 1C998-595-2 1C998-595-2		シャッター部組 SHUTTER UNIT	1	8		1	
* 1C998-599 1C998-599		三脚基板部組 TRIPOD BASE PLATE UNIT	1	15		5	
* 1C998-601-1 1C998-601		SQ基板部組 SQ BASE PLATE UNIT	1	4		1	
* 1C998-603 1C998-603		DC/DCシールド板 DC/DC SHIELD PLATE	1	3		1	
* 1C998-605 1C998-605		絞り制御基板部組 APERTURE CONTROL BASE UNIT	1	6		1	