


2. Shooting image adjustment software

Adjustments of Parts to be replaced	Sensitivity	Gr/Gb compensation ADJ (R/B filter)	Sensitivity ratio	CCD black point defect compensation	CCD white point defect compensation	TFT view angle	CCD- PCB EEPROM Flash up	TFT EEPROM Flashram up
Shutter unit								
Main PCB unit								
AF sensor unit								
DC/DC PCB unit								
Metering FPC unit								
Memory compression PCB							○	○
CF PCB								
I/F PCB								
CCD PCB unit	○	○	○	○	○			
TFT PCB or TFT monitor						○		*○

*. Execute "TFT EEPROM Flash up" first, then adjust "TFT view angle".

~~Check the type of TFT monitor (NEW or OLD) before execute "TFT EEPROM Flash up".~~  (Deletion)

